

PRESS TO EXIT

DOOR RELEASE

Exit Button

- White plastic
- Surface mount
- COM / NO / NC
Change-over-contacts

H	W	D
85	85	27



PRESS TO EXIT

DOOR RELEASE

Exit Button

- Gloss white plastic
- Surface mount
- COM / NO / NC
Change-over-contacts

H	W	D
85	85	25

